

Toner Cartridge

Installation Instructions

FOR USE IN

TK410/TK411/TK418 , TK420/TK421/TK428 , TK438/TK448/TK435 , TK437/TK458
TASKalfa 220, ASKalfa 221, KM-1635, KM-2035, KM-2550
TASKalfa 180, TASKalfa 181, KM-1620, KM-1650, KM-2050, KM-1648,

